COOKTOP PARTS

For Model: SF315PEGW5, SF315PEGN5, SF315PEGQ5, SF315PEGT5,SF315PEGV5
(White) (Almond) (Designer White) (Designer Biscuit) (Biscuit)

30" GAS FREESTANDING
STANDARD CLEAN RANGE
SEALED BURNER



Illus. No.	Part No.	DESCRIPTION
1		Literature
	LIT8273167	Instructions, Installation
	LIT3195945	Installation, Instructions (Template)
	LIT8273145	Guide,Use & Care
	LIT8053556	Tech Sheet
	LIT3191638	Safer Cooking Tips
2		Cap,Burner(RR)
	3191898	Black
	3191899	Grey
		Cap,Burner(LR,RF)
	3191901	Black
	3191903	Grey
		Cap,Burner(LF)
	3191904	Black
	3191905	Grey
4	8273214	Burner (LF)
	8273215	Burner (LR,RF)
	8273216	Burner (RR)
5		Cooktop
	8272251	White
	8272252	Almond
	8272743	Biscuit
6		Panel, Manifold
	8273027	Black
	8273025	White
	8273028	Biscuit
7		Knob, Control (3)
	8273103	Black
	8273104	White
	8273106	Biscuit
8		Grate, Burner (4)
	8053458	Black
	8053391	Grey
9		Knob, Powerburner
	8273111	Black
	8273112	White
	8273114	Biscuit
10	3195813	Clip, Cooktop (2)
12	3195060	Hinge, Cooktop (2)
13	3196178	Screw
14	3368921	Screw
15	3196557	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Model: SF315PEGW5, SF315PEGN5, SF315PEGQ5, SF315PEGT5,SF315PEGV5
(White) (Almond) (Designer White) (Designer Biscuit) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1		Endcap
		Left Hand
	3186188	Black
	3186190	White
	8272507	Biscuit
		Right Hand
	3186189	Black
	3186191	White
	8272508	Biscuit
2		Support, Endcap
	3186198	Left Hand
	3186199	Right Hand

Illus. No.	Part No.	DESCRIPTION
3		Panel, Backguard
	3195773	Black
	3195774	White
	8273793	Biscuit
4	4449746	Screw
5	8053421	Module, Spark
7	3196200	Clip, Spring (2)
8	8272474	Cover, Upper
9	8053910	Shield, Heat
10	8273132	Cover, Lower

Illus. No.	Part No.	DESCRIPTION
12		Control, Range
	6610151	Black
	6610152	White
	6610285	Biscuit
13	3196178	Screw
14	3196427	Screw
18		Switch, Rocker
	3148564	Black
	3149360	White
	8273501	Biscuit
19	8273564	Clip

MANIFOLD PARTS

For Model: SF315PEGW5, SF315PEGN5, SF315PEGQ5, SF315PEGT5,SF315PEGV5

(White) (Almond) (Designer White) (Designer Biscuit) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Model: SF315PEGW5, SF315PEGN5, SF315PEGQ5, SF315PEGT5,SF315PEGV5
(White) (Almond) (Designer White) (Designer Biscuit) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	8273096	Screw, Valve (4)
2		Burner Base
	8272895	Large (3)
	8273019	Small (1)
3		Tubing, Burner W/Orifice
	8272903	(LF)
	8273142	(LR)
	8272905	(RF)
	8272907	(RR)
4	8273131	Tubing (Manifold to Regulator)
5	8273075	Harness, Igniter (Incl. Switches)
6	8273061	Electrode (4)
7	8272411	Pipe, Manifold
8	8272976	Valve (LF,LR,RF)
	8273004	Valve (RR)
9	8273060	Nut (4)
10	8273062	Screw (4)
12	8053970	Spreader, Flame
14	3186476	Burner, Bake/Broil
15	3195008	Valve, Gas Combo
16	3186491	Igniter, Bake/Broil
17	3196385	Screw
18	3196178	Screw
19	3196176	Screw
20		Orifice,Burner
	8273064	(LF)
	8273066	(LR)
	8273065	(RF)
	8273067	(RR)

Following Parts Not Illustrated

	8273176	Spuds, LP Gas (Kit of 4)

CHASSIS PARTS

For Model: SF315PEGW5, SF315PEGN5, SF315PEGQ5, SF315PEGT5,SF315PEGV5
(White) (Almond) (Designer White) (Designer Biscuit) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Model: SF315PEGW5, SF315PEGN5, SF315PEGQ5, SF315PEGT5,SF315PEGV5
(White) (Almond) (Designer White) (Designer Biscuit) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	3195727	Flue Box
3	8273036	Burner Box
4		Panel, Side (2)
	8053830	White−Textured
	8053831	Almond−Textured
	8272519	Biscuit−Textured
5	3196576	Clip, Panel (6)
6		Brkt, Manifold Mtg
	3186405	Left Hand
	3186406	Right Hand
7	3196072	Plug, Frame
8		Frame, Front (Non−Serviceable)
9	3196037	Foot, Front (2)
10	312701	Foot, Rear (2)
11	3195097	Bottom, Oven
12	3196966	Sensor, Oven
13	3186056	Baffle, Base
14	8053335	Rail, Base (2)
16	310345	Switch, Door
17	3195809	Bumper (2)
18	3196701	Socket Assembly
19	311255	Bulb, Light
20	8272921	Back, Main
21	3186152	Seal, Oven
22	3195994	Glide, Front (2)
23		Plate, Guide
	3195732	Left Hand
	3195731	Right Hand
24	8054037	Cord, Power
25	3196256	Clamp, Cord
26		Button, Plug
	3196439	5/16" (2)
	3196440	25/32" (2)
	8054083	Oval (1)
27	3196537	Screw
28	3196178	Screw
29	3196179	Screw
31	3196152	Screw
32	3196165	Screw
33	3196173	Screw
34	3196183	Screw (Back / Regulator)

INSULATION

	8272617	Insulation, Wrap
	3195927	Tie, Insulation
	8272614	Insulation, Back

BROILER PARTS

For Model: SF315PEGW5, SF315PEGN5, SF315PEGQ5, SF315PEGT5,SF315PEGV5
(White) (Almond) (Designer White) (Designer Biscuit) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (2)
2	3195996	Grill, Broiler
3	3196076	Pan, Broiler
4	3195558	Pushnut (2)
5		Bracket, Hinge
	3195269	Left Hand
	3195268	Right Hand
6		Spring, Hinge
	3195267	Left Hand
	3195205	Right Hand

Illus. No.	Part No.	DESCRIPTION
7	3196179	Screw
8	3148182	Bumper, Door (2)
9	3195739	Liner, Brlr Door
10	3196426	Screw, Handle (2)
11	3195551	Bracket, Standoff
12		Panel, Door
	3186087	White
	3195096	Almond
	8273504	Biscuit

Illus. No.	Part No.	DESCRIPTION
13		Handle, Brlr Door
	3186090	Black
	3195189	White
	8273505	Biscuit
14	3196645	Spacer, Handle (2)
15	3196178	Screw
16	3195733	Guide, Upper (2)
17	3195730	Glide, Broiler (2)
20	3196168	Screw
21	3186079	Carriage, Broiler
22	3186097	Pin, Pivot (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Model: SF315PEGW5, SF315PEGN5, SF315PEGQ5, SF315PEGT5,SF315PEGV5
(White) (Almond) (Designer White) (Designer Biscuit) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1		Trim, Top
	3196819	Black
	3196821	White
	8272494	Biscuit
2	3196164	Screw, Handle (2)
3		Handle, Door
	3195922	Black
	3195218	White
	8272495	Biscuit
4	3186296	Liner, Door
5	8272618	Insulation, Door
6	3186284	Window, Inner
7	3186303	Retainer, Insul.
8	8053808	Hinge, Door (2)
9		Glass, Outer
	8053479	Black
	8053481	White
	8273525	Biscuit
10		Trim, Side
		Left Hand
	3195976	Black
	3195974	White
	8272497	Biscuit
		Right Hand
	3195973	Black
	3195971	White
	8272496	Biscuit
11	3196160	Screw
12		Trim, Lower
	3195424	Black
	3195422	White
	8272499	Biscuit
15	3196161	Screw
16	3196071	Plug, Door
17	3196025	Clip, Glass (4)
18	3195809	Bumper, Door (2)
21	3196925	Clip, Door Stop
22	3196165	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Model: SF315PEGW5, SF315PEGN5, SF315PEGQ5, SF315PEGT5,SF315PEGV5
(White) (Almond) (Designer White) (Designer Biscuit) (Biscuit)

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated

SPLICING WIRES−−25FT. LENGTH

242828	Wire, Black 12 Ga. 150° c
242820	Wire, Black 14 Ga. 150°c
242821	Wire, Blue 14 Ga. 150°c
242822	Wire, Brown 14 Ga. 150°c
242830	Wire, Brown 14 Ga. 200°c
242823	Wire, Green 14 Ga. 150°c
242824	Wire, Orange 14 Ga. 150°c
242829	Wire, Red 12 Ga. 150°c
242825	Wire, Red 14 Ga. 150°c
242831	Wire, Red 14 Ga. 200°c
242826	Wire, White 14 Ga. 150°c
242827	Wire, Yellow 14 Ga. 150°c
242832	Wire, Yellow 14 Ga. 200°c

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch−Up Self−Clean(1/2 Pt)
261582	Grease

INSULATION

261514	Insulation, Fiberglass (1−1/2" x 24" x 120")
240132	Insulation, Fiberglass (2−1/2" x 22" x 120")

PAINT, TOUCH−UP (1/2oz.)

72017	White
72107	Almond
4392899	Biscuit
511873	White Porcelain (2 Oz.)

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)
4392900	Biscuit (Uncut)

ACCESSORY PARTS

241430	Foil, Aluminum Oven (18" x 25')

ANTI−TIP KIT

3176830	Anti−Tip Kit

WIRING HARNESS PARTS

8053527	Clip, Wire
8053587	Harness−Wire (Oven)
8273341	Harness,Electrode
3196896	Clip−Wire
313438	Clip, Harness
3196520	Clip, Wire

Miscellaneous

814381	Pin Kit−Dr Removal